


### 3.3.3 Program operation 2nd operation screen


► Screen indicating command value, set value, control output value, and lamp (LAMP) operation status



[Picture 3-9] Program (PROGRAM) | 2nd Operation Screen

- ① The ON state is indicated in red and the OFF state is indicated in dark gray.
- ② Indicates the current program block number.
- ☞ [Program Number: 000/000] The previous number indicates the number of executed segments, and the following numbers indicate the set number of segments.
- ③ Indicates the mode repeat state.
- ☞ [Mode Repeat Count : 000/000] The previous number indicates the number of iterations that have been executed, and the following numbers indicate the number of iterations.
- ④ Indicates the running PID number.
- ⑤ Indicates the total time the program is currently running.
- ⑥ Indicates the time of the current run and the time set by the segment.
- ⑦ Indicates a partial repeat state.
- ☞ [SEG repeat count : 000/000] The previous number indicates the number of iterations that have been executed, and the following numbers indicate the number of iterations.
- ⑧ Switch from the current screen to the next screen.
- ⑨ Maintain (HOLD ON) or release (HOLD OFF) the current temperature and humidity settings. (Wewon Environmental Chambers Co., Ltd. Copyright)

### 3.4.1 Real-time Fault Display




[Picture 3-10] Real-Time Fault Display Screen

### 3.4.2 Historical Fault Inquiry Screen


3.4 Fault Display Screen





[Picture 3-11] Historical Fault Display Screen

▶ Additional functions of the general machine and additional settings related to the setting of the fixed value. **4. Run Related Operation Settings**



[Picture 4-1] Operation Related Operation Setting Screen

- ① Select a setting from the program and the fixed value run.
- ② Fixed slope setting.
- ③ Set the running time.
- ④ The setting function waits for the setting.


Table 4-1. Operation Mode Setting Parameters

Parameter	Predetermined area	Unit	Initial value
Operation mode	Fixed value		Value
Fixed timing	0.00 ~ 300.00	HH.MM (hours. minutes)	0.00

Description: When set to 0.00, the setting timing is invalid, press the stop button to stop the unit.

## 5. Program Group Setting

▶ When the program group setting button is clicked in [3.1 Main Screen], the screen changes to [Picture 5-1 Program Group Setting Screen].



[Picture 5-1] Program Setting Screen

	Indicating content	Description
①	Program group	100 sets of programs can be set (1~100)
②	Test name	Can set 30 bytes
③	Program group editing	Switch to the program editing screen
④	Cycle setting	Switch to the cycle setting screen
⑤	Waiting for setting	Switch to the wait setting screen
⑥	Time signal	Switch to the time setting screen



5.1 Program group mode setting

[Picture 5-2] Program Editing Screen

①	Indicates the segment order number.
②	Set the temperature of the block to be run
③	Set the humidity of the block to be run.
④	Set the time of the block to be run.
⑤	Set the time signal of the block to be run.
⑥	Switch to the next block editing screen.
⑦	Insert the block and click this button to increase the number of segments by one. (Wewon Copyright)
⑧	Delete the block, click this button, and delete the number of segments.
⑨	Click the [Program] button to switch to [Picture 5-1 Program Group Settings Screen].
▶	Click the [Program Group] button to display the input box for setting the program number.