

7 Screen display settings

7.1 Screen display settings



[Figure 7-1] Screen display settings


- ① Language selection.
- ② The entire set of buttons in the monitor screen is displayed.
- ③ Calibrate touch screen.
- ④ Set whether to use prompt tone.
 - ☞ Even if the setting is not used, the DI fault occurs when the prompt tone will not be closed.
- ⑤ Can be set back light energy saving time.
 - ☞ Energy saving working time setting is to refer to no need to operate the button, how long the back light lamp is closed.
- ⑥ Set user password.

7.2 DI Fault record view

▶ Display the breakdown of the DI type and date, time of the screen.

▶ Fault records can show up to 30.

☞ If the failure number more than 30, starting from the front to delete fault number, after the occurrence of the fault will meet at the end.



[Figure 7-2] DI fault record screen

- ① Display DI fault record.
- ☞ Read only status, not change.
- ② Delete all DI fault record.
- ③ Can view the previous or next fault record.