

8 Time setting

- ▶ Set the current time and the time to make an appointment.



[Figure 8-1] Time setting screen

- ① Set the current year, month, day, and time.
 - ☞ The current time can not be changed during the operation.
- ② Set an appointment to run a year, month, day, and time.
- ③ Click (make an appointment) key, which can be run in the set time.
 - ☞ Click (make an appointment) key, as shown in Figure 8-2 running appointment settings screen, will show the appointment time on the running screen.



Figure 8-2] running an appointment to set the screen